

CROSS REFERENCE LIST **CONNECTORS**

| IC connector P/N --> | JST P/N | JST P/N --> | IC connector P/N |
|--------------------------------|-----------------------|-----------------------|-------------------------|
| 0800IDC-XXW-U | 02SUR-xxS | 02SUR-xxS | 0800IDC-XXW-U |
| 0800MR-XXTW-U | SBMXXB-SURS-TF | 08FMS-1.0SP-TF | FPC3BMR6-08TBT-U |
| 0800MS-XXTW-U | BMXXB-SURS-TF | BMxxB-SRDS-G-TF | 1001MS-2XXGW-U |
| 1001-G-L | SSH-003T-P0.2(Gold) | BMxxB-SRSS-TB | 1001MS-1XXTW-U |
| 1001H-1XXW1-L | SHR-xxV-S-B | BMXXB-SURS-TF | 0800MS-XXTW-U |
| 1001H-2XXW-L | SHDR-xxV-S-B | BXPS-VH | 3962R-XXTW-L |
| 1001MR-1XXTW-U | SMxxB-SRSS-TB | BXP-VN | 3962S-XXTW-L |
| 1001MS-1XXTW-U | BMxxB-SRSS-TB | BxxB-PHDSS | 2004R-2XXTW-L |
| 1001MS-2XXGW-U | BMxxB-SRDS-G-TF | BxxB-PH-KL | 2001S-XXTW-L |
| 1001-T-L | SSH-003T-P0.2(Tin) | BxxB-PH-SM3-TB | 2001MS-XXGW-U |
| 1500H-03W-L | ZHR-3 | BxxB-XH-A | 2503S-XXTW-L |
| 1500H-03W-L | ZHR-3 | BxxB-ZR | 1500S-XXTW-L |
| 1500H-03W-L | ZHR-3 | BxxB-ZR-SM3A-TF | 1500MS-XXGW-U |
| 1500H-03W-L | ZHR-3-M | Bxx-EH-A | 2505S-XXTW-L |
| 1500H-XXW-L | ZHR-xx | HER-xx | 2505H-XXW-L |
| 1500MR-XXGW-U | SxxB-ZR-SM3A-TF | JST B2B-PH-K-S | 2001S-02TW-L |
| 1500MS-XXGW-U | BxxB-ZR-SM3A-TF | JST B4B-PH-SM3-TB | 2001MS-04GW-U |
| 1500R-XXTW-L | SxxB-ZR | JST B5B-PH-SM3-TB | 2001MS-05GW-U |
| 1500S-XXTW-L | BxxB-ZR | JST B6B-EH-A | 2505S-06TW-L |
| 1500TB-L | SZH-002T-P0.5 | JST B7B-EH-A | 2505S-07TW-L |
| 1500TB-L | SZH-002T-P0.5 | JST B7B-PH-SM3-TB | 2001MS-07GW-U |
| 1500-T-L | SZH-002T-P0.5 | JST B8B-PH-SM3-TB | 2001MS-08GW-U |
| 2001H-03W-L | PHR-3 | JST B9B-PH-SM3-TB | 2001MS-09GW-U |
| 2001H-03W-L | PHR-3 | JST S8B-PH-SM3-TB(LF) | 2001MR-08GW-U |
| 2001H-03W-L | PHR-3 | JST VBR-XX | 5083H-XXW-L |
| 2001H-03W-L | PHR-3-BK | PHR-3 | 2001H-03W-L |
| 2001H-03W-L | PHR-3-M | PHR-3 | 2001H-03W-L |
| 2001H-04W-L | PHR-4 | PHR-3 | 2001H-03W-L |
| 2001H-04W-L | PHR-4-R | PHR-3-BK | 2001H-03W-L |
| 2001H-04W-L | PHR-4-Y | PHR-3-M | 2001H-03W-L |
| 2001H-05W-L | PHR-5-R | PHR-4 | 2001H-04W-L |
| 2001H-05W-L | PHR-5-R | PHR-4-R | 2001H-04W-L |
| 2001H-05W-L | PHR-5-R | PHR-4-Y | 2001H-04W-L |
| 2001H-06W-L | PHR-6 | PHR-5-R | 2001H-05W-L |
| 2001H-06W-L | PHR-6 | PHR-5-R | 2001H-05W-L |
| 2001H-XXW-L | PHR-xx | PHR-5-R | 2001H-05W-L |
| 2001MR-08GW-U | JST S8B-PH-SM3-TB(LF) | PHR-6 | 2001H-06W-L |
| 2001MR-XXGW-U | SxxB-PH-SM3-TB | PHR-6 | 2001H-06W-L |
| 2001MS-04GW-U | JST B4B-PH-SM3-TB | PHR-xx | 2001H-XXW-L |
| 2001MS-05GW-U | JST B5B-PH-SM3-TB | S10B-PHDSS | 2004R-205TW-L |
| 2001MS-07GW-U | JST B7B-PH-SM3-TB | SAN-002T-08 | 2005-T-L |
| 2001MS-08GW-U | JST B8B-PH-SM3-TB | SAN-002T-08 | 2005-RT-L |
| 2001MS-09GW-U | JST B9B-PH-SM3-TB | SBMXXB-SURS-TF | 0800MR-XXTW-U |

CROSS REFERENCE LIST IC CONNECTORS

| IC connector P/N --> | JST P/N | JST P/N --> | IC connector P/N |
|--------------------------------|----------------------|-----------------------|-------------------------|
| 2001MS-XXGW-U | BxxB-PH-SM3-TB | SCN-001T-P1.0 | 2501-T-L |
| 2001R-XXTW-L | SxxB-PH-KL | SHDR-xxV-S-B | 1001H-2XXW-L |
| 2001S-02TW-L | JST B2B-PH-K-S | SHE-001T-P0.6 | 2505-T-L |
| 2001S-XXTW-L | BxxB-PH-KL | SHR-xxV-S-B | 1001H-1XXW1-L |
| 2001TB-L | SPH-002T-P0.55 | SMxxB-SRSS-TB | 1001MR-1XXTW-U |
| 2001TB-L | SPH-002T-P0.5S | SPH-002T-P0.55 | 2001TB-L |
| 2001TB-L | SPH-002T-P0.5S | SPH-002T-P0.5S | 2001-T-L |
| 2001TB-L | SPH-002T-P0.5S | SPH-002T-P0.5S | 2001TB-L |
| 2001TB-L | SPH-002T-P0.5S | SPH-002T-P0.5S | 2001TB-L |
| 2001TB-L | SPH-002T-P0.5S | SPH-002T-P0.5S | 2001TB-L |
| 2001-T-L | SPH-002T-P0.5S | SPH-002T-P0.5S | 2001TB-L |
| 2004R-205TW-L | S10B-PHDSS | SPH-002T-P0.5S | 2001TB-L |
| 2004R-2XXTW-L | BxxB-PHDSS | SSH-003T-P0.2(Gold) | 1001-G-L |
| 2004S-2XXTW-L | SxxB-PHDSS | SSH-003T-P0.2(Tin) | 1001-T-L |
| 2005H-XXW-L | XXP-SAN | SVH-21T-P1.1 | 3962-T-L |
| 2005RH-XXW-L | XXP-SAN, RIGHT ANGLE | SVH-21T-P1.1 | 3962-TB-L |
| 2005-RT-L | SAN-002T-08 | SXH-001T-P0.6 | 2503-T-L |
| 2005-T-L | SAN-002T-08 | S-xxB-EH | 2505R-XXTW-L |
| 2501H-XXW-L | xxP-SCN | SxxB-PHDSS | 2004S-2XXTW-L |
| 2501-T-L | SCN-001T-P1.0 | SxxB-PH-KL | 2001R-XXTW-L |
| 2503H-XXW-L | XHP-xx | SxxB-PH-SM3-TB | 2001MR-XXGW-U |
| 2503R-XXTW-L | SxxB-XH-A | SxxB-XH-A | 2503R-XXTW-L |
| 2503S-XXTW-L | BxxB-XH-A | SxxB-ZR | 1500R-XXTW-L |
| 2503-T-L | SXH-001T-P0.6 | SxxB-ZR-SM3A-TF | 1500MR-XXGW-U |
| 2505H-XXW-L | HER-xx | SZH-002T-P0.5 | 1500-T-L |
| 2505R-XXTW-L | S-xxB-EH | SZH-002T-P0.5 | 1500TB-L |
| 2505S-06TW-L | JST B6B-EH-A | SZH-002T-P0.5 | 1500TB-L |
| 2505S-07TW-L | JST B7B-EH-A | VHR-2N | 3962H-02W-L |
| 2505S-XXTW-L | Bxx-EH-A | VHR-XN | 3962H-XXW-L |
| 2505-T-L | SHE-001T-P0.6 | XHP-xx | 2503H-XXW-L |
| 3962H-02W-L | VHR-2N | XXFLZ-RSM1-TB | FPC4AMR1-XXTNBR-U |
| 3962H-XXW-L | VHR-XN | XXP-SAN | 2005H-XXW-L |
| 3962R-XXTW-L | BXPS-VH | XXP-SAN, RIGHT ANGLE | 2005RH-XXW-L |
| 3962S-XXTW-L | BXP-VN | xxP-SCN | 2501H-XXW-L |
| 3962-TB-L | SVH-21T-P1.1 | ZHR-3 | 1500H-03W-L |
| 3962-T-L | SVH-21T-P1.1 | ZHR-3 | 1500H-03W-L |
| 5083H-XXW-L | JST VBR-XX | ZHR-3 | 1500H-03W-L |
| FPC3BMR6-08TBT-U | 08FMS-1.0SP-TF | ZHR-3-M | 1500H-03W-L |
| FPC4AMR1-XXTNBR-U | XXFLZ-RSM1-TB | ZHR-xx | 1500H-XXW-L |